



SPRAY MASK Transfer Mounting Instructions

- 1) The Spray Mask Transfer consists of three layers. From bottom to top there is the white backing stock, white cut spray mask transfer with special medium tack adhesive which resists the solvents in your paint, and clear application tape (or sometimes paper) for positioning the decal.
- 2) From any corner, peel up the application tape. At the same time, the spray mask letters will lift off of the backing stock. If one of the letters doesn't lift up, lay the application tape back down on it and rub down with your fingernail. Peel up again.
- 3) Looking through the application tape and using the register arrows for alignment position the transfer on the frame. Rub down thoroughly with your fingers while trying to avoid trapping air bubbles under the mask. Now burnish the mask down completely, making good contact with the frame surface.
- 4) Peel back the application tape leaving the spray mask letters on the frame. Pick off any register arrows. At this point inspect the transfer to make sure all the edges are making good contact with the frame and that the positioning is correct.
- 5) Spray the frame, when the paint has reached tack, using a knife or needle pick at the corner of the Spray Mask and gently peel it off taking extreme care as to not mess up the paint job.